



**I NO Monteringsanvisning
desentralt ventilasjonssystem
med varmegjenvinning
Type e^{GO}**

03.20 v.11

- videreleveres til brukeren -

**II EN Installation Manual
Decentralised Ventilation System
with Heat Recovery
Type e^{GO}**

- Please pass on to user -

Monteringsanvisning

NO

Innhold

Side:

Om denne veiledningen, sikkerhetsråd, tekniske data, avhending	2
Målskisser, plassering av ventilasjonsenheten, bruksområde	3
Innhold i emballasjen	4
Montasje: Monteringsrør	5
Montasje: Elektrisk Installasjon og elektrisk tilkobling	6
Montasje: Ventilatorinnsats og innvendig deksel	7
Montasje: utvendig deksel, lukking av innvendig deksel	9
Filterbytte, sommerstilling, rengjøring, tilleggs- og byttedeler	10

Om denne veiledningen

- Les denne veiledningen i sin helhet før motering påbegynnes! Følg alltid de generelle sikkerhetsrådene og henvisninger til symboler med notater i teksten.
- Denne veiledningen skal overleveres til brukeren (leietaker, eier, eiendomsforvalter, etc.) etter at installasjonen er slutført.

Symboler i denne veiledningen:



Dette symbolet advarer om fare for skade



Dette symbolet advarer om fare for skade fra elektrisk strøm

Sikkerhetsanvisninger



Advarsel! Ved alt monasjearbeide på ventilasjonsutstyret skal nettspenning være frakoblet, (med allpolig brudd). Ventilasjonsutstyret er elektrisk isolert i beskyttelsesklasse II, (KI.II) også betegnet som „Dobbeltisolert“.



OBS! Elektrisk tilkobling til nettspenning, (220 Volt AC), skal gjøres av autorisert personell.



OBS! Utstyret skal ikke betjenes (eks. filterbytte, renhold) av barn eller personer som grunnet fysisk, sensorisk eller mentale evner, uerfarenhet eller uvitenhet, ikke er i stand til å betjene utstyret på en sikker måte. Barn bør ikke leke med ventilasjonsutstyret.


Technische Daten

Strømtilførsel, nettspenning	230 Volt, 50 Hz
Driftspenning, ventilator:	12 Volt DC SELV
Kapslingsgrad, (IP-klasse):	IP 22
Luftmengder:	5; 10; 15; 20 m³/h i gjenvinningsmodus, 45 m³/h i avtrekksmodus

Entsorgen




Entsorgen Sie die Verpackung sortenrein. Wenn Sie sich vom Gerät trennen möchten, entsorgen Sie es zu den aktuellen Bestimmungen. Auskunft erteilt die kommunale Stelle.



Plassering

To vifter er i drift i e⁹⁰, alltid i motsatt retning (i varme-gjenvinningsmodus), og sørger for samtidig avtrekk og tilførsel av luft.

Minsteavstand til vegg eller andre komponenter i omgivelsene må ivaretas, for å sikre uhindret luftstrøm uten uønsket blanding av tilført og uttrukket luft.





Driftsområde

Temperaturområde: - 15°C til + 40°C

Ventilatorenheten kan benyttes ved innendørs relativ luftfuktighet opp til 65%, (ikke kondenserende). Hvis overskridelse av grensene for driftsområdene skulle forekomme, skal enheten slås av og innvendig deksel lukkes. Frisk luft kan så tilføres ved å åpne vinduer.

Kontrollér at leveransen er komplett og uten skader!


Montasjerør

e⁹⁰- ventilatorinnsats

Utvendige deksler

Utvendig deksel, 1/EGA


Best. nr.: 040 019



Utvendig stormkappe, 2 typer:

1/HWE-2 hvit Best. nr.: 040 107


1/HAZ-2 antrasit Best. nr.: 040 108




Lag åpning i yttervegg for rørinstallasjon (f.eks ved kjerneboring, bordiameter 162 mm).

Forkort røret etter behov til ønsket lengde. Påse at det er god tetting mellom rørets ytre del og veggen, (etter at røret er satt inn og at rørender flukter med veggoverflatene både utvendig og innvendig).


Røret festes/tettes mot vegg med f.eks. montasjelim. Ved montering i trevegg anbefales mansjett for å tette mot vindsperre.



Slutfør innvendig og utvendig pushing/sparkling.



Forbered kabling for ventilatorenhet i angitt område. (flertrådig, 6 x 0,75mm² fra styring til ventilator,) Ekstra kabellengde ca 100-120 mm. Benytt medfølgende boremal!



Sikkerhetsanvisninger




Forsiktig! Alt monteringsarbeide for ventilasjonssystemet skal kun gjøres ved allpolig frakoblet nettspenning! Før tilkobling av ventilator til nettspenning skal alle tilkoblingsleder gjøres spenningsfrie! (frakobles nett med minst 3 mm kontaktåpning, f.eks. allpolig frakobling med elektrisk sikring).




Strømtilførsel til ventilasjonssystemet skal gjøres via forskriftsmessige elektrisk vern! Elektrisk tilknytning til nettspenning skal utføres av autorisert personell!

Styring kan gjøres med ulike produkttyper levert fra Lunos. For disse gjelder de tilsvarende installasjonsanvisninger. Velg plassering av bryterpanel. Trekk frem kabler. Legg nettkabel for strømtilførsel frem til nettdelen (eks. 3x1,5mm²). Et lavere tverrsnitt er tilstrekkelig mellom nettdel, styringsenhet og ventilatorer, 6 x 0,75mm². (for kortere føringsveier vil også 6 x 0,5mm² være tilstrekkelig)




Benytt medfølgende bormal for å bore festehull for innvendig ventilatorramme. Bruk om nødvendig medfølgende ekspansjonsplugg.



NB.: Påse at montering skjer som vist med markeringen „OPP“. Avvik fra dette tillates ikke av strømningstekniske årsaker!




Fjern beskyttelsesdeksel. Forkort EPP-adapteret til samme lengde som monteringsrøret. Hvis rørets lengde overskrider 500mm monteres ytterligere EPP-adaptore!




Skyv inn vifteenheten med innvendig ventilatorramme, varmeveksler og EPP-adaptør inn i monteringsrøret.



Kabelen trekkes gjennom gummigjennomføringen i innvendig ventilatorramme til koblingsfeltet. Fest innvendig ventilatorramme til veggen med de medfølgende skruer.




Ventilatorenheten kobles til




Monter dekselet for koblingsfeltet, og plassér stengningsplatene oppå! Sett inn filterne og klips dekselet på plass.

Bruk bormalen og bor feste-hullene. Benytt ekspansjonspluggen etter behov, og i samsvar med veggmateriale. (Se også „Montering av innvendig ventilatorramme“, figur 1)


Plassér utvendig festeramme mot EPP-adapter som viste i figuren.




Monter utvendig festeramme med de medfølgende skruer. Plassér utvendig deksel på festerammen, eventuelt for stormkappen av metall.


Stenging av innvendig ventilatorramme

Den innvendige ventilatorrammen kan avstenges ved behov med de magnetiske stengeplatene: Plassér stengeplatene på innsiden av gitterne, med rød side utover. Sett på plass innvendig deksel.



Når filteret er forurenses varsles dette med lysdiode I henhold til beskrivelse i anvisningen for den type styring som er benyttet. Ventilatorens innvendige deksel tas av og filteret fjernes. Nytt eller vasket filter settes inn (standardfilter kan f.eks vaskes under springen eller i oppvaskmaskin). Innvendig deksel settes tilbake på plass. Ventilatoråpningen må ikke tildekkes eller tettes igjen. Tilbakestilling av filtervarsling gjøres i henhold til styringens anvisning.



Notater om utførte filterbytter:

Dato for filterbytte:	Neste forventede filterbytte:	Montert filtertype:

Sommerstilling

Med denne funksjonen økes reverseringstiden for ventilatorene til én time. D.v.s. ventilatorene går én time i tiluftsmodus og én time i avtrekksmodus.

Reinigung


Ved behov, tørk av innvendig deksel og ramme med en tørr eller lett fuktet klut. Filterskifte og rengjøring av ventilatorenhets bør ikke utføres av barn eller personer som grunnet fysiske, sensoriske eller mentale evner, uerfarenhet eller uvitenhet ikke er i stand til å utføre dette på en sikkerhetsmessig betryggende måte.

Tilleggs-og reservedeler

Filter G3 type 9/FEGO-3R, 4-pakning
Pollenfilter type 9/FEGO-P 4-pakning
EPP-adapter type 2/AD 160

Bestillingsnr.: 039 998
Bestillingsnr.: 039 982
Bestillingsnr.: 039 965



Norge

Lavenergisystemer AS
Olav Brunborgs vei 6
1396 Billingstad

Telefon 944 76 073
post@lunos.no
www.lunos.no



**I NO Monteringsanvisning
desentralt ventilasjonssystem
med varmegjenvinning
Type e^{GO}**

03.20 v.11

- videreleveres til brukeren -

**II EN Installation Manual
Decentralised Ventilation System
with Heat Recovery
Type e^{GO}**

- Please pass on to user -

Installation Manual English

EN

Contents

Page:

About this manual, Safety instructions, Technical data, Disposal	12
Dimension diagrams, Installation position, Range of application	13
Shipping units	14
Assembly: Assembly tube	15
Assembly: Electrical installation and electrical connection	16
Assembly: Fan insert, inside room screen	17
Assembly: Outer screen, Closing the inner screen	19
Filter replacement	20
Summer ventilaton, Cleaning, Additional parts and replacement parts	20

About this manual

- Read this manual carefully and completely before assembly. Always observe the general safety instructions and the safety symbols with information in the text.
- Hand out this manual to the user (tenants, proprietors, property management etc.) after completing assembly.

Symbols in this manual



This symbol warns you against risks of injury



This symbol warns you against risks of injury from electricity

Safety instructions



Caution! Any assembly work to the ventilation device may only be carried out after disconnecting all poles of the supply voltage. The ventilation device is fitted with protective insulation according to Protection Class II, a protective conductor connection is not required.



Attention! The electric connection may only be made by authorised qualified personnel and according to the applicable version of VDE 0100.



Attention! This device must not be operated by children and persons (filter replacement/cleaning) who are not able to operate the device safely due to their physical, sensory or mental abilities or their inexperience or lack of knowledge. Children should be supervised to ensure that they do not play with the device.


Technical data

Supply voltage:	230 VAC 50 Hz
Device voltage:	12 VDC SELV
Protection Class:	IP 22
Airflow volume:	5; 10; 15; 20 m³/h in reverse operation, 45 m³/h in exhaust air mode

Disposal




The packaging must be sorted before disposal. If you wish to dispose of the ventilation device, observe the current regulations. The competent municipal authority will provide information.



Installation position

The two fans in the e⁹⁰ always operate in opposite directions thus providing supply and exhaust air simultaneously. Minimum distances to the wall and surrounding components must be observed to ensure unobstructed air flow without inadmissible mixing of supply and exhaust air!




Range of application


Temperature range of application: - 15°C to + 40°C
Can be used at a relative humidity up to 65% in the interior room area (not condensing). If the application limits are exceeded, switch off the device and close the inner screen. Ensure supply of fresh air via window ventilation.

Please check your delivery for completeness and mint condition!

Assembly tube




e⁹⁰ - insert




Outer screens


Outer screen, type 1/EGA
Order-No.: 040 019




Prepare wall openings for the assembly tubes (e.g. via core drill hole, core bit Ø162 mm). If necessary, shorten the tube to the installation length required. Make sure there is a slight projection of the tube on both sides to bridge the plaster thickness (after plastering, the tube must be flush with the plaster). Insert the tube and seal it all-round (Assembly adhesive Order No. 038 733).



Apply the inside and outside plaster.



Prepare the cable for the device connection in the designated section (e.g. J-Y (ST) Y4x2x0,8). Cable length approx. 100 to 120 mm. Use the drilling template.



Safety instructions



Caution! Any assembly work to the ventilation device may only be carried out after disconnecting all poles of the supply voltage!

Make sure that the supply voltage of all connection lines is voltage-free (dead)! (Separation from the power supply with a minimum contact opening of 3 mm, e.g. electric fuse separating all poles).


Each electric circuit of this ventilation system must be fitted with a residual current protection (e.g. FI switch/ RCCB)!



Electric connection only by a specialist!


Additional installations and electrical components in the ventilation unit are not allowed!

Triggering can be made via various LUNOS-controls. The respective installation instructions apply accordingly. Select the position of the switch. Slit the cable channels. Connect the cable to the switch and locate the power pack under the switch e.g. 3x 1.5mm², otherwise a smaller cross-section suffices e.g. J-Y (ST)Y 4 x 2 x 0.8) and the cables to the devices (e.g. J-Y(ST)Y 4 x 2 x 0.8). Switching and switch are connected in accordance with the connection plan displayed below.




Drill the fastening bores for the inside room screen using the drilling template and insert the dowels enclosed.



Note: Observe the label 'TOP', any deviating installation position is not admissible for flow-related reasons!




Remove the plaster protection cap. Shorten the EPP adapter to the length of the assembly tube. In the case of tube lengths above 500 mm, additional adapter pieces may be mounted!




Insert the fan unit (inner housing sub-part, heat exchanger unit and EPP adapter) into the assembly tube!



Insert the connection cable through one of the boots of the inner housing sub-part in the section of electrical connection! Fasten the inner housing sub-part to the wall using the screws enclosed!




Connect the ventilation unit!
(Connection plan, refer to p 5)




Mount the cover for the electrical connection section and insert the closing element on top!! Insert the filter and snap the cover into place!

Using the drilling template, drill the fastening drill holes and insert dowels (in accordance with the surface) provided on-site (refer to "Assembly: Inside room screen", Image 1). Place the outer screen sub-part on the EPP adapter located in the tube!




Fasten the outer screen sub-part using the screws enclosed! Place the cover on top!!




Closing the inner screen

The inner screen can be closed, if required, using the magnetic closing elements: Place the closing elements with the red side outwards from the inside in front of the fan grille! Apply the cover!



The filter replacement indicator signals that a filter is contaminated. For further information please read the instructions of your LUNOS-control. Remove design screen, take filter out, insert new or cleaned filter (filters can be cleaned e.g. in a dishwasher), put design screen on. The ventilation openings must not be blocked or covered.



Please enter the filter changes you have carried out:

Filter replacement date	Expected filter replacement	Type of filter used

Summer ventilation

In this function the reversing time of the fan is increased to 1 hour, i.e. the fan runs in supply air mode for one hour, in the following hour in exhaust air mode etc..

Cleaning

! If necessary wipe the indoor screen and covering frame with a dry soft cloth. Filter replacement and cleaning must not be carried out by children or by persons who are not able to operate the device safely due to their physical, sensory or mental abilities or their inexperience or lack of knowledge.

Additional parts and replacement parts

Filter G3 Type 9/FEGO-3R, four-pack	Order No.: 039 998
Pollenfilter Type 9/FEGO-P, four-pack	Order No.: 039 982
EPP Adapter Type 2/AD 160	Order No.: 039 965



Lavenergisystemer AS
Olav Brunborgs vei 6
1396 Billingstad

Telefon 944 76 073
post@lunos.no
www.lunos.no